



# ***Modified Bayer Process for Alumina Removal from Hanford Waste***



**Don Geniesse**  
**AREVA NC Inc.**

***January 24, 2007***



# ***Alumina Removal Team***

- ▶ ***AREVA NC - Don Geniesse, Eric Nelson,  
Gary Stegen***
- ▶ ***Penn State - Dr. Tony Perotta***
- ▶ ***RJ Lee - Randy Hermann, Marisol Avila***

# ***Hanford Alumina Problem***

***Current Waste Na*** ***44,000 MT***

***Additional Na to Leach Al*** ***30,000 MT***

***Total Na to WTP*** ***74,000 MT***

- ▶ ***Additional Na needed to leach Al sludge increases WTP Na by 68%***
- ▶ ***Additional Na increases WTP glass volume and treatment schedule proportionally***
- ▶ ***Soluble Al can plug WTP equipment by forming amorphous gel during filtration, ion exchange, cooling, dilution, and/or neutralization operations in WTP***

# Alumina Solubility

- ▶ **Alumina solubility is highly temperature dependent**



- ▶ **Alumina has poor solubility at 25°C**



**~4 moles excess NaOH required to maintain 1 mole  $\text{Al(OH)}_4^{-1}$  soluble at 25°C**

- ▶ **Alumina has enhanced solubility at 100°C**




**~1 mole excess NaOH is required to maintain 1 mole  $\text{Al(OH)}_4^{-1}$  soluble at 100°C**

- ▶ **Precipitation of gibbsite regenerates hydroxide**



- ▶ **Elevated temperature leaching and cooling precipitation regenerates hydroxide for additional leaching – reducing or eliminating NaOH demand for leaching alumina**



***Gibbsite Solubility is Strongly Dependent on Temperature***

# Modified Bayer Process

- ▶ **Conventional method used by aluminum industry leaches alumina from bauxite @ 150°C & precipitates gibbsite @ 60°C in seeded solution**
- ▶ **Proposed Modified Bayer Process leaches alumina sludge at 100°C and precipitates clean, crystalline gibbsite at 60°C**
- ▶ **Bayer process regenerates hydroxide for additional alumina leaching**
- ▶ **Clean, precipitated gibbsite may be used as a WTP glass former, reducing total glass volume by offsetting imported glass formers**

# Modified Bayer Process Experiments

## DST Simulant Tests




Leach At 100°C - Seed, and  
Precipitate  $\text{Al}(\text{OH})_3$  at 60°C



Filter and Wash  
Precipitate

# Precipitation Methods


- ▶ **Cooling Precipitation** - for regenerating NaOH and recycling leachate solution
- ▶ **Dilution Precipitation** - improved yield for regenerating NaOH & recycling leachate
- ▶ **Partial Neutralization** – precipitates nearly all alumina for one-pass operation (no leachate recycle)
- ▶ **Lithium Alumina Carbonate Precipitation**–



***Removes nearly all alumina and allows recycle of strong leachate solution***




# 60°C Cooling Gibbsite Precipitation



**75% of Theoretical Yield in 24 Hours**  
**~100% in 4 days**

# 60°C Cooling & Dilution Gibbsite Precipitation




**Single Pass Yield Improved 40% by 1:1 Dilution**

# ***Partial Neutralization Gibbsite Precipitation***


- ▶ ***Partial Neutralization precipitates soluble alumina from supernatants to prevent downstream plugging (60°C supernatants can gel when cooled to 25°C)***
- ▶ ***Partial neutralization done under same conditions as cooling precipitation (60°C & seeded)***
- ▶ ***Supernatant neutralized with 10% HNO<sub>3</sub> to pH endpoint of 11***

# Partial Neutralization $\text{Al}(\text{OH})_3$ Precipitation




**96% of Total Alumina Removed by Partial Neutralization**

# Product Cake Decontamination



**Product Easily Filtered - 99.7%  $\text{Al}(\text{OH})_3$  Purity**  
**Cs Removed in Proportion to Wash Ratio**

# Gibbsite Crystal Size




***Precipitation Occurs by Seed Growth***

# ***Hanford Application of Modified Bayer Process***

- 1. Leach alumina sludge in-situ from tank sludge, decant supernatant & precipitate alumina as clean gibbsite by Modified Bayer Process***
- 2. Precipitated gibbsite is decontaminated with wash water to remove interstitial (Cs, Tc, I) contamination***
- 3. Evaporate filtrate to re-constitute leach liquor & recycle***
- 4. Partially neutralize supernatants to precipitate gibbsite from WTP feed***
- 5. Use recovered, decontaminated  $\text{Al}(\text{OH})_3$  as glass former in WTP melters***

# Modified Bayer Process

## Preliminary Process Flow Diagram






# ***Pneumapress® Filter***



***Simple, Contained Filter Press***


# Boehmite ( $\text{AlOOH}$ ) Solubility



**Boehmite is more stable & less soluble than gibbsite**


- ▶ ***Modified Bayer Process is a simple and effective method for removing and decontaminating soluble alumina and gibbsite sludge from Hanford Waste***
- ▶ ***Existing equipment (DSTs, evaporators) may be used to reduce capital cost***
- ▶ ***Process may be enhanced by dilution, partial neutralization, or lithium alumina carbonate precipitation to pre-condition liquor for WTP feed***
- ▶ ***Boehmite removal requires more robust leaching and/or precipitation conditions than gibbsite***

# Modified Bayer Process for Alumina Removal from Hanford Waste



## Proposed Phase 2 Approach:

**Bench Scale Testing of  
Alumina Leaching,  
Precipitation, Filtration,  
& Evaporation**




## ***Phase 2 Bench Tests 10 Liter Scale***

- ▶ ***Gibbsite & Boehmite Leaching from Simulated Sludge***
- ▶ ***Seeded Gibbsite Precipitation***
- ▶ ***Pressure Filtration/Wash Testing***
- ▶ ***Seed Recycle***
- ▶ ***Evaporation & Recycle of Filtrate***



## ***Phase 2 Pilot Tests*** ***500 gallon Scale***

- ▶ ***Vendor Tests will use Simulated Waste/C-31 Seed Slurry***
- ▶ ***Tests will determine Capacity of Full-Scale System using 5 gpm pilot unit***
- ▶ ***Full-scale Wash/Cake Decontamination Factors***
- ▶ ***Cake Handling Properties***




MODEL 12-304

# ***Phase 2 Laboratory Tests***

## ***1 Liter Scale***

- ▶ ***Boehmite Leaching/Gibbsite Precipitation***
- ▶ ***Lithium Alumina Carbonate Crystallization***
- ▶ ***Effects of Organic Contaminants***
- ▶ ***Alternate Waste Compositions***





# Phase 2

## *Future Work Summary*

***Phase 2 Work will Optimize Process Parameters for Design of Full-scale System and Specify Conditions for Hot Work Testing***

- ▶ ***Precipitation Residence time***
- ▶ ***Amount of Seed and Extent of Seed Recycle***
- ▶ ***Amount of Wash and Extent of Decontamination***
- ▶ ***Evaporation & Recycle of Filtrate for Leaching***
- ▶ ***Potential Application of Lithium Alumina Carbonate***
- ▶ ***Boehmite Leaching***
- ▶ ***Alternate Waste Composition & Effects of Organics***