

Appendix F: Glossary

A

accuracy—Closeness of the result of a measurement to the true value of the quantity.

actinide—Group of radioactive metallic elements of atomic number 89 through 103. Laboratory analysis of actinides by alpha spectrometry generally refers to the elements plutonium, americium, uranium, and curium but may also include neptunium and thorium.

activity—See radioactivity.

alpha particle—Positively charged particle emitted from the nucleus of an atom having the same charge and mass as that of a helium nucleus (two protons and two neutrons)

ambient—Existing in the surrounding area. Completely enveloping.

ambient air—Surrounding atmosphere as it exists around people, plants, and structures.

analyte—Constituent or parameter that is being analyzed.

analytical detection limit—Lowest reasonably accurate concentration of an analyte that can be detected; this value varies depending on the method, instrument, and dilution used.

aquifer—Saturated, permeable geologic unit that can transmit significant quantities of water under ordinary hydraulic gradients.

Area Completion Project—U.S. Department of Energy program that directs the assessment and cleanup of inactive waste units and groundwater (remediation) contaminated as a result of nuclear-related activities.

Atomic Energy Agency—Federal agency created in 1946 to manage the development, use, and control of nuclear energy for military and civilian application. It was abolished by the Energy Reorganization Act of 1974 and succeeded by the Energy Research and Development Administration. Functions of the Energy Research and Development Administration eventually were taken over by the U.S. Department of Energy and the U.S. Nuclear Regulatory Commission.

audit—A systematic evaluation to determine the conformance to quantitative specifications of some operational function or activity.

B

Background control location—A sampling point that is not impacted by SRS operations.

background radiation—Naturally occurring radiation, fallout, and cosmic radiation. Generally, the lowest level of radiation obtainable within the scope of an analytical measurement, that is, a blank sample.

Benchmark — A standard or point of reference against which things may be compared or assessed.

Best Available Technology (BAT) —The preferred technology for treating a particular process liquid waste. BAT is not a specific level of treatment but the conclusion of a selection process that includes several treatment alternatives. The selection process looks at factors related to technology, economics, public policy, and other parameters.

best management practices—Sound engineering practices that are not required by regulation or by law.

beta particle—Negatively charged particle emitted from the nucleus of an atom. It has a mass and charge equal to those of an electron.

Biobased products—Products derived from plants and other renewable agricultural, marine, and forestry materials that provide an alternative to conventional petroleum-derived products.

Biopreferred[®] —A program the U.S. Department of Agriculture (USDA) manages to increase the purchase and use of biobased products. The program's purpose is to spur economic development, create new jobs, and provide new markets for farm commodities. For more information, please see the [USDA website](#).

biota—Plant and animal life.

blind sample—A subsample for analysis with a composition known to the submitter. The analyst or laboratory may know the identity of the sample, but not its composition. It tests the analyst's or laboratory's proficiency in the execution of the measurement process.

C

calibration—Process of applying correction factors to equate a measurement to a known standard. Generally, a documented measurement control program of charts, graphs, and data that demonstrate that an instrument is properly calibrated.

canyon—Two facilities located at SRS where nuclear materials are chemically recovered and purified. They are called “canyons” because of their similarity to how a canyon looks, open space with high wall-like mountains on either side of a valley.

Carolina bay—Type of shallow depression commonly found on the coastal Carolina plains. Carolina bays are typically circular or oval. Some are wet or marshy, while others are dry.

categorical exclusion—Categories of actions that do not individually or cumulatively have a significant effect on the human environment and for which, therefore, neither an environmental assessment nor an environmental impact statement is required.

Central Savannah River Area—Eighteen-county area in Georgia and South Carolina surrounding Augusta, Georgia. The Savannah River Site is included in the Central Savannah River Area. Counties are Richmond, Columbia, McDuffie, Burke, Emanuel, Glascock, Jenkins, Jefferson, Lincoln, Screven, Taliaferro, Warren, and Wilkes in Georgia and Aiken, Edgefield, Allendale, Barnwell, and McCormick in South Carolina.

chlorocarbons—Compounds of carbon and chlorine, or carbon, hydrogen, and chlorine, such as carbon tetrachloride, chloroform, tetrachloroethylene, etc. They are among the most significant and widespread environmental contaminants. Classified as hazardous wastes, chlorocarbons may have a tendency to cause detrimental effects, such as birth defects.

cleanup—Actions taken to deal with release or potential release of hazardous substances. This may mean complete removal of the substance; it also may mean stabilizing, containing, or otherwise treating the substance so that it does not affect human health or the environment.

closure—Control of a hazardous waste management facility under Resource Conservation and Recovery Act requirements.

compliance—Fulfillment of applicable requirements of a plan or schedule ordered or approved by government authority.

composite—A blend of more than one portion to be used as a sample for analysis.

Comprehensive Environmental Response, Compensation, and Liability Act (CERCLA)—This Act addresses the cleanup of hazardous substances and establishes a National Priority List of sites targeted for assessment and, if necessary, restoration (commonly known as “Superfund”).

concentration—Amount of a substance contained in a unit volume or mass of a sample.

conductivity—Measure of water’s capacity to convey an electric current. This property is related to the total concentration of the ionized substances in water and the temperature at which the measurement is made.

contamination—State of being made impure or unsuitable by contact or mixture with something unclean, bad, etc.

contaminant pathway—The way contaminants move and settle in the environment after release from operating facilities to the air and water.

continuous assessment—Evaluation of a program or employee carried out on a fixed interval (for example, weekly, monthly, annually)

control chart—A graph of some measurement plotted over time or sequence of sampling, together with control limit(s) and, usually, a central line and warning limit(s). Control charts provide a graphical representation of accuracy and precision, a long-term mechanism for self-evaluation of analytical data, and an assessment of analytical capability of the laboratory analyst.

control standard—A standard prepared independently of and run with the calibration. It is used to verify the accuracy of the calibration.

cool roof—A thick white rubber-type roof that lowers the temperature of standard roofs from about 150 degrees Fahrenheit to 100 degrees or less.

criteria pollutant—Six common air pollutants found all over the United States. They are particle pollution (often referred to as particulate matter), ground-level ozone, carbon monoxide, sulfur dioxide, nitrogen oxides, and lead. The Clean Air Act requires the Environmental Protection Agency to set National Ambient Air Quality Standards for these six pollutants.

curie—Unit of radioactivity. One curie is defined as 3.7×10^{10} (37 billion) disintegrations per second. Several fractions and multiples of the curie are commonly used:

- **kilocurie (kCi)**— 10^3 Ci, one thousand curies; 3.7×10^{13} disintegrations per second.
- **millicurie (mCi)**— 10^{-3} Ci, one-thousandth of a curie; 3.7×10^7 disintegrations per second.
- **microcurie (μ Ci)**— 10^{-6} Ci, one-millionth of a curie; 3.7×10^4 disintegrations per second.
- **picocurie (pCi)**— 10^{-12} Ci, one-trillionth of a curie; 0.037 disintegrations per second.

D

DCS sum of fractions—The sum of the ratios of the average concentration of each radionuclide to its corresponding DCS value. (See below for definition of DCS-derived concentration standard.)

decay (radioactive)—Spontaneous transformation of one radionuclide into a different radioactive or nonradioactive nuclide, or into a different energy state of the same radionuclide.

deactivation—The process of placing a facility in a stable and known condition, including removing hazardous and radioactive materials to ensure adequate protection of the worker, public health and safety, and the environment, thereby limiting the long-term cost of surveillance and maintenance.

decommissioning—Process that takes place after deactivation and includes surveillance and maintenance, decontamination, and dismantlement.

decontamination—The removal or reduction of residual radioactive and hazardous materials by mechanical, chemical, or other techniques to achieve a stated objective or end condition.

derived concentration standard (DCS)—Concentration of a radionuclide in air or water that, under conditions of continuous exposure for one year by one exposure mode (that is, ingestion of water, submersion in air, or inhalation), would result in an effective dose equivalent of 0.1 rem (1 mSv). The guides for radionuclides in air and water are given in U.S. Department of Energy Derived Concentration Technical Standard (DOE-STD-1196-2011) (DOE 2011).

detection limit—See analytical detection limit, lower limit of detection, minimum detectable concentration.

detector—Material or device (instrument) that is sensitive to radiation and can produce a signal suitable for measurement or analysis.

disposal—Permanent or temporary transfer of U.S. Department of Energy control and custody of real property to a third party, which thereby acquires rights to control, use, or relinquish the property.

disposition—Those activities that follow completion of program mission including, but not limited to, surveillance and maintenance, deactivation, and decommissioning.

dissolved oxygen—Desirable indicator of satisfactory water quality in terms of low residuals of biologically available organic materials. Dissolved oxygen prevents the chemical reduction and subsequent leaching of iron and manganese from sediments.

DOECAP—A comprehensive audit program for contract laboratories with the intent of conducting consolidated audits to eliminate redundant audits previously conducted independently by DOE field element sites and to achieve standardization in audit methodology, processes, and procedures.

dose—Energy imparted to matter by ionizing radiation. The unit of absorbed dose is the rad, equal to 0.01 joules per kilogram in any medium.

- **absorbed dose**—Quantity of radiation energy absorbed by an organ, divided by the organ's mass. Absorbed dose is expressed in units of rad (or gray) (1 rad = 0.01 Gy).
- **equivalent dose**—Product of the absorbed dose (rad) in tissue and a radiation weighting factor. Equivalent dose is expressed in units of rem (or sievert) (1 rem = 0.01 sievert).
- **effective dose**—Sum of the dose equivalents received by all organs or tissues of the body after each one has been multiplied by an appropriate tissue weighting factor.
- **committed effective dose**—Is the effective dose integrated over time, usually 50 years. Committed effective dose is expressed in units of rem (or sievert).
- **collective dose**—Sum of the effective dose of all individuals in an exposed population within a 50-mile (80-km) radius and expressed in units of person-rem (or person-sievert). The 50-mile distance is measured from a point located centrally with respect to major facilities or U.S. Department of Energy program activities.

dosimeter—Portable detection device for measuring the total accumulated exposure to ionizing radiation.

drinking water standards—Federal primary drinking water standards, both proposed and final, as set forth by the Environmental Protection Agency.

duplicates or duplicate results—Results derived by taking a portion of a primary sample and performing the same analysis on that portion that is performed on the primary sample.

E

effluent—A release of treated or untreated water or air from a pipe or a stack to the environment. Liquid effluent flows into a body of water such as a stream or lake. Airborne effluent (also called emission) discharges into the atmosphere.

effluent monitoring—Collection and analysis of samples or measurements of liquid and gaseous effluents to characterize and quantify the release of contaminants, assess radiation exposures to members of the public, and demonstrate compliance with applicable standards.

emission—A release of a gas.

ENERGY STAR[®]—A U.S. Environmental Protection Agency program that helps businesses and individuals save money and protect the climate through energy efficiency. For more information, please visit the [ENERGY STAR website](#).

environmental compliance—Actions taken in accordance with government laws, regulations, orders, etc., that apply to Site operations' effects on onsite and offsite natural resources and on human health; used interchangeably in this document with regulatory compliance.

environmental monitoring—Vital role in determining health and safety issues for the purpose of public health or environmental health. Environmental monitoring at Savannah River Site includes effluent monitoring and environmental surveillance with the dual purpose of 1) showing compliance with federal, state, and local regulations, as well as with U.S. Department of Energy orders, and 2) monitoring any effects of Site operations on onsite and offsite natural resources and on human health.

environmental occurrence—Any sudden or sustained deviation from a regulated or planned performance at a DOE operation that has environmental protection and compliance significance.

environmental surveillance—Collection and analysis of samples of air, water, soil, foodstuffs, biota, and other media from U.S. Department of Energy sites and their environs and the measurement of external radiation to demonstrate compliance with applicable standards, assess radiation exposures to members of the public, and assess effects, if any, on the local environment.

EPEAT—A product database that registers products based on the devices' ability to meet various criteria developed and agreed upon by diverse stakeholders to address the full lifecycle of an electronic product. This system ensures all products listed in the EPEAT database truly represent environmental leadership. For more information, please visit the [EPEAT website](#).

exception (formerly “exceedance”)—Term used by the Environmental Protection Agency and the South Carolina Department of Health and Environmental Control that denotes a reported value is more than the guide limit. This term is found on the discharge monitoring report forms that are submitted to the Environmental Protection Agency or the South Carolina Department of Health and Environmental Control.

exclusion or exclusion device—Material or equipment used for wildlife control. These devices may be used to deter animal use of an area, to provide a method of collecting animals, or to provide a means of exit for an animal.

exposure (radiation)—Incidence of radiation on living or inanimate material by accident or intent. Background exposure is the exposure to natural background ionizing radiation. Occupational exposure is the exposure to ionizing radiation that takes place during a person’s working hours. Population exposure is the exposure to the total number of persons who inhabit an area.

exposure pathway—The way that a person could be impacted from releases of radionuclides into the water and air.

F

fallout—The settling to the ground of airborne particles ejected into the atmosphere from the earth by explosions, eruptions, forest fires, etc. or from human production activities such as found at nuclear facilities.

Federal Facility Agreement (FFA)—Agreement negotiated among the U.S. Department of Energy, the U.S. Environmental Protection Agency, and the South Carolina Department of Health and Environmental Control, specifying how the Savannah River Site will address contamination or potential contamination to meet regulatory requirements at Site waste units identified for evaluation and, if necessary, cleanup.

feral hog—Hog that has reverted to the wild state from domestication.

field duplicate—An independent sample collected as closely as possible to the same point in space and time as the original sample. The duplicate and original are two separate samples taken from the same source, stored in separate containers, and analyzed independently.

fiscal year—An established period of time when an organization's annual financial records start and end. In the federal government, this period is from October 1 to September 30.

fugitive greenhouse gas emissions—The inadvertent release of greenhouse gases to the atmosphere from various facilities or activities. Some common sources include leaks or releases from valves, pumps, compressors, flanges from refrigeration, and air conditioning systems.

G

global fallout—Radioactive debris from atmospheric weapons tests that has been deposited on the earth's surface after being airborne and cycling around the earth.

grab sample—Sample collected instantaneously with a glass or plastic bottle placed below the water surface to collect surface water samples (also called dip samples).

graded approach (to sampling)—A decision process in which the requirements on the system vary with the risk of exposure to radionuclides.

gross alpha and beta releases—The total alpha-emitting and beta-emitting activity determined at each effluent location.

ground shine—Exposure to gamma radiation produced by radioactive materials on the ground surface is called ground shine and it contributes to external dose.

groundwater—Water found underground in cracks and spaces in soil, sand, and rocks.

H

half-life (radiological)—Time required for half of a given number of atoms of a specific radionuclide to decay. Each nuclide has a unique half-life.

hazardous waste—Any waste that is a toxic, corrosive, reactive, or ignitable material that could affect human health or the environment.

I

impaired water— Water for which technology-based regulations and other required controls are not stringent enough to meet the water quality standards set by states.

International Organization for Standardization (ISO)—Creates documents that provide requirements, specifications, guidelines, or characteristics that can be used consistently to ensure that materials, products, processes, and services are compatible with their purpose. For more information, please visit the [ISO website](#).

intralaboratory checks—Compare performance within a laboratory by analyzing duplicate and blind samples throughout the year.

isotope—Each of two or more forms of the same element that contain equal numbers of protons but different numbers of neutrons in their nuclei and, hence, differ in relative atomic mass but not in chemical properties; in particular, a radioactive form of an element.

L

legacy—Anything handed down from the past; inheritance, as of nuclear waste.

low-level waste—Waste that includes protective clothing, tools, and equipment that have become contaminated with small amounts of radioactive material.

lower limit of detection—Smallest concentration or amount of an analyte that can be reliably detected in a sample at a 95% confidence level.

M

manmade radiation—Radiation from sources such as consumer products, medical procedures, and nuclear industry.

MAPEP—A laboratory comparison program that tracks performance accuracy and tests the quality of environmental data reported to DOE.

maximally exposed individual—Hypothetical individual who remains in an uncontrolled area and would, when all potential routes of exposure from a facility's operations are considered, receive the greatest possible dose equivalent.

maximum contaminant level—The maximum allowable concentration of a drinking water contaminant as legislated through the Safe Drinking Water Act.

mercury—Silver-white, liquid metal solidifying at -38.9°C to form a tin-white, ductile, malleable mass. It is widely distributed in the environment and biologically is a nonessential or nonbeneficial element. Human poisoning due to this highly toxic element has been clinically recognized.

migration—Transfer or movement of a material through the soil or groundwater.

minimum detectable concentration (radionuclides)—Smallest amount or concentration of a radionuclide that can be distinguished in a sample by a given measurement system at a preselected counting time and at a given confidence level.

minimum detectable concentration (chemicals)—Smallest amount or concentration of a chemical that can be distinguished in a sample by a given measurement system at a given confidence level.

mixed waste—Waste that has both hazardous and radioactive components.

monitoring—Process whereby the quantity and quality of factors that can affect the environment or human health are measured periodically to regulate and control potential impacts.

N

nonroutine radioactive release—Unplanned or nonscheduled release of radioactivity to the environment.

nuclide—Atom specified by its atomic weight, atomic number, and energy state. A radionuclide is a radioactive nuclide.

O

organic—Of, relating to, or derived from living organisms (plant or animal).

optically stimulated luminescence dosimeter (OSLD)— A reusable passive device that measures the exposure from ionizing radiation. In 2019, SRS transitioned from TLDs to OSLDs to obtain a higher and more accurate absorption rate to radiation exposure.

outfall—Place where treated or untreated water flows out of a pipe to mix with water from a water body, such as a stream or lake.

P

parameter—Analytical constituent; chemical compound(s) or property for which an analytical request may be submitted.

passive device—A device that does not require a source of energy for its operation.

PCB bulk product waste—Waste derived from products manufactured to contain PCBs in a nonliquid state at 50 ppm or greater. Typical examples are caulk, paint, and sealants.

performance evaluation (PE) sample—A sample, the composition of which is unknown to the analyst, that is provided to test whether the analyst or laboratory can produce analytical results within specified performance limits.

person-rem—Collective dose to a population group. For example, a dose of 1 rem to 10 individuals results in a collective dose of 10 person-rem.

pH—Measure of the hydrogen ion concentration in an aqueous solution (acidic solutions, pH <7; basic solutions, pH >7; and neutral solutions, pH 7).

piezometer—Instrument used to measure the potentiometric surface of the groundwater. Also, a well designed for this purpose.

plume—Volume of contaminated water originating at a waste source for example, a hazardous waste disposal site). It extends downward and outward from the waste source.

plume shine—Exposure to gamma radiation from airborne radioactive materials is called plume shine (sometimes called cloud shine or sky shine), and it contributes to external dose.

point source—Any defined source of emission to air or water such as a stack, air vent, pipe, channel, or passage to a water body.

population dose—See collective dose equivalent under dose.

potable water—Water that is safe to drink.

practical quantitation—The lowest level a laboratory can quantify with 99% confidence.

precision—A estimate of the degree to which a set of observations or measurements of the property, usually obtained under similar conditions agree. It is a data quality indicator.

process sewer—Pipe or drain, generally located underground, used to carry off either process water or waste matter, or both.

proficiency testing—An evaluation of a laboratory's performance against preestablished criteria by means of interlaboratory comparison. It is also known as comparative testing.

purge—To remove water prior to sampling, generally by pumping or bailing.

Q

quality assurance (QA)—An integrated system of management activities involving planning, implementation, documentation, assessment, reporting, and quality improvement to ensure quality in the processes by which products are developed.

quality control (QC)—A set of activities for ensuring quality in products by identifying defects in the actual products.

R

rad—Unit of absorbed dose deposited in a volume of material.

radioactivity—Spontaneous emission of radiation, generally alpha or beta particles, or gamma rays, from the nucleus of an unstable isotope.

radioisotopes—Radioactive isotopes.

radionuclide—Unstable nuclide capable of spontaneous transformation into other nuclides by changing its nuclear configuration or energy level. This transformation is accompanied by the emission of photons or particles.

Recovery criteria—The ratio of the observed mean result and the value of a standard

reference person—A hypothetical age and gender averaged individual that is a combination of human (male and female) physical and physiological characteristics arrived at by international consensus to standardize radiation dose calculations.

RCRA/CERCLA Units—Units subject to the remedial action process established in the Federal Facilities Agreement.

Regional Screening Level (RSL)—The risk-based concentration derived from standardized equations combining exposure assumptions with toxicity data.

regulatory compliance—Actions taken in accordance with government laws, regulations, orders, etc., that apply to Savannah River Site operations' effects on onsite and offsite natural resources and on human health; used interchangeably in this document with environmental compliance.

release—Any discharge to the environment. Environment is broadly defined as any water, land, or ambient air.

rem—Unit of dose equivalent (absorbed dose in rads times the radiation quality factor). Dose equivalent frequently is reported in units of millirem (mrem), which is one thousandth of a rem.

remediation—Assessment and cleanup of sites contaminated with waste due to historical activities.

representative person—A hypothetical individual receiving a dose that is representative of the more highly exposed individuals in the population.

Resource Conservation and Recovery Act (RCRA)—Federal legislation that regulates the transport, treatment, and disposal of solid and hazardous wastes. This act also requires corrective action for releases of hazardous waste at inactive waste units.

retention basin—Unlined basin used for emergency, temporary storage of potentially contaminated cooling water from chemical separations activities.

routine radioactive release—Planned or scheduled release of radioactivity to the environment.

S

seepage basin—Excavation that receives wastewater. Insoluble materials settle out on the floor of the basin and soluble materials seep with the water through the soil column, where they are removed partially by ion exchange with the soil. Construction may include dikes to prevent overflow or surface runoff.

SEER—Seasonal Energy Efficiency Ratio—This is a measure of equipment energy efficiency over the cooling season. It represents the total cooling of a central air conditioner or heat pump during the normal cooling season as compared to the total electric energy input consumed during the same period.

sensitivity—Capability of methodology or instruments to discriminate between samples with differing concentrations or containing varying amounts of an analyte.

sievert—The International System of Units (SI) derived unit of dose equivalent. It attempts to reflect the biological effects of radiation as opposed to the physical aspects, which are characterized by the absorbed dose, measured in gray. One sievert is equal to 100 rem.

significant analytical result—Indicates that the result is statistically significant or is at or above the detection limit of the applicable radioanalytical method, or both.

Silvex— A herbicide and a plant growth regulator. It has been banned for use as a herbicide in the United States since 1985.

site stream—Any natural stream on the Savannah River Site. Surface drainage of the Site is via these streams to the Savannah River.

source—Point or object from which radiation or contamination emanates.

source term—Quantity of radioactivity (released in a set period of time) that is traceable to the starting point of an effluent stream or migration pathway.

spent nuclear fuel—Used fuel elements from reactors.

splits or split sample—Two or more representative portions taken from a single sample and analyzed by different analysts or laboratories. Split samples are used to replicate the measurement of the parameters of interest.

SRS Community Reuse Organization (SRSCRO)—A nonprofit organization charged with developing and implementing strategy to diversify the economy in the five South Carolina and Georgia counties surrounding the Site. For more information, please see the [SRSCRO website](#).

stable—Not radioactive or not easily decomposed or otherwise modified chemically.

stack—Vertical pipe or flue designed to exhaust airborne gases and suspended particulate matter.

standard deviation—Indication of the dispersion of a set of results around their average.

statistical data evaluation—A collection of methods used to process large amounts of data and report overall trends.

stormwater runoff—Surface streams that appear after precipitation.

Superfund—See Comprehensive Environmental Response, Compensation, and Liability Act (CERCLA).

surface water—Water that has not penetrated below the surface of the ground.

T

tank farm—Interconnected underground tanks used for storage of high-level radioactive liquid wastes.

temperature—Thermal state of a body, considered with its ability to communicate heat to other bodies.

terrestrial—Living on or growing from the land.

thermoluminescent dosimeter (TLD)—A passive device that measures the exposure from ionizing radiation.

total dissolved solids—Dissolved solids and total dissolved solids are terms generally associated with freshwater systems; they consist of inorganic salts, small amounts of organic matter, and dissolved materials.

total phosphorus—May occasionally stimulate excessive or nuisance growths of algae and other aquatic plants when concentrations exceed 25 mg/L at the time of the spring turnover on a volume-weighted basis in lakes or reservoirs.

total suspended particulates—Refers to the concentration of particulates in suspension in the air, regardless of the nature, source, or size of the particulates.

translocation—The deliberate movement of organisms from one site for release in another. It must be intended to yield a measurable conservation benefit at the levels of a population, species or ecosystem, and not only provide benefit to translocated individuals.

transport pathway—Pathway by which a released contaminant is transported physically from its point of discharge to a point of potential exposure to humans. Typical transport pathways include the atmosphere, surface water, and groundwater.

transuranic waste—Solid radioactive waste containing primarily alpha-emitting elements heavier than uranium.

trend—General drift, tendency, or pattern of a set of data plotted over time.

tritium—Elemental form of the radioactive isotope of hydrogen and occurs as a gas.

tritium oxide—Water in which the tritium isotope has replaced a hydrogen atom. Stack releases of tritium oxide typically occur as water vapor.

turbidity—Measure of the concentration of sediment or suspended particles in solution.

U

unidentified alpha and beta releases—The unspecified alpha and beta releases that are conservatively determined at each effluent location by subtracting the sum of the individually measured alpha-emitting (for example, plutonium-239 and uranium-235) and beta-emitting (for example, cesium-137 and strontium-90) radionuclides from the measured gross alpha and beta values, respectively. Unidentified alpha and beta releases also include naturally occurring radionuclides, such as uranium, thorium, radon progeny, and potassium-40.

utility water—Once-through noncontact cooling water, recirculated noncontact cooling water, boiler blowdown, steam condensate, air conditioning condensate, and other uncontaminated heating, ventilation, and air conditioning or compressor condensates.

V

volatile organic compounds—Broad range of organic compounds, commonly halogenated, that vaporize at ambient, or relatively low, temperatures (for example, acetone, benzene, chloroform, methyl alcohol).

W

waste management—The U.S. Department of Energy uses this term to refer to the safe, effective management of various kinds of nonhazardous, hazardous, and radioactive waste generated at DOE facilities.

waste unit—A particular area that is or may be posing a threat to human health or the environment. Waste units range in size from a few square feet to tens of acres and include basins, pits, piles, burial grounds, landfills, tank farms, disposal facilities, process facilities, and groundwater contamination.

waste stream—Waste material generated from a single process or from an activity that is similar in material, physical form, isotopic makeup, and hazardous constituents.

WaterSense[®]—A U.S. Environmental Protection Agency partnership that offers ways to increase water efficiency through products and services. For more information, please visit the [U.S. EPA website](#).

water table—Planar, underground surface beneath which earth materials, such as soil or rock, are saturated with water.

Waters of the State—Surface or underground water within the jurisdiction of the state, as defined in the South Carolina Pollution Control Act.

weighting factor—Value used to calculate dose equivalents. It is tissue-specific and represents the fraction of the total health risk resulting from uniform, whole-body irradiation that could be attributed to that particular tissue. The weighting factors used in this report are recommended by the International Commission on Radiological Protection (Publication 26).

wetland—Lowland area, such as a marsh, swamp, bog, Carolina bay, floodplain bottom, where land is covered by shallow water at least part of the year and is characterized by somewhat mucky soil.